

## CARTUCHOS E ACESSÓRIOS

### CARTUCHO EM LATAO COM ROSCA (R26)



Código	Ref.	Ø	Torque de abert. em alojamentos de material plástico [Nm]	Torque de abert. em alojamentos metálicos [Nm]
<b>SERIES R</b>				
2026A02	R26	3	0.6	0.8
2026A01	R26	3.17	0.6	0.8
2026001	R26	4	0.8	1
2026002	R26	5	0.8	1.5
2026003	R26	6	0.8	1.2
2026004	R26	8	1	1.8
2026005	R26	10	0.8	2
2026006	R26	12	0.8	2

### MACHO PARA SEDE DO CARTUCHO R26



Código	Ref.
2025020	MA R26 3-3.17
2025021	MA R26 4
2025022	MA R26 5
2025023	MA R26 6
2025024	MA R26 8
2025025	MA R26 10
2025026	MA R26 12

### CARTUCHO EM LATAO TIPO COMPRESSAO (R27)



Código	Ref.	Ø
<b>SERIES R</b>		
2027001	R27	4
2027002	R27	5
2027003	R27	6
2027004	R27	8
2027005	R27	10
2027006	R27	12

### FERRAMENTA DE PREPARAÇÃO DA SEDE DO CARTUCHO R26



Código	Ref.
2025010	UT.SE. R26 3-3.17
2025011	UT.SE. R26 4
2025012	UT.SE. R26 5
2025013	UT.SE. R26 6
2025014	UT.SE. R26 8
2025015	UT.SE. R26 10
2025016	UT.SE. R26 12

### FERRAMENTA DE PREPARAÇÃO DA SEDE DO CARTUCHO R27



Código	Ref.
<b>FOR ALUMINIUM</b>	
2027021	UT.SE. R27 AL. 4
2027022	UT.SE. R27 AL. 5
2027023	UT.SE. R27 AL. 6
2027024	UT.SE. R27 AL. 8
2027025	UT.SE. R27 AL. 10
2027026	UT.SE. R27 AL. 12

### FOR TECHNOPOLYMER

2027011	UT.SE. R27 P. 4
2027012	UT.SE. R27 P. 5
2027013	UT.SE. R27 P. 6
2027014	UT.SE. R27 P. 8
2027015	UT.SE. R27 P. 10
2027016	UT.SE. R27 P. 12

### CHAVE PARA CARTUCHOS R26 (R41)



Código	Ref.	Ø
2041001	R41	4
2041002	R41	5
2041003	R41	6
2041004	R41	8
2041005	R41	10
2041006	R41	12

### CHAVE DE DESMONTAGEM DE TUBOS (R17)



Código	Ref.	Ø Tubo
2L17001	RL17	de 3 a 10
2017001	R17	de 4 a 14