

## CONEXÕES EM TECNOPOLÍMERO

### RETO INTERMEDIÁRIO (R19)



Código	Ref.	Ø
2019001	RL19	4
2019002	RL19	5
2019003	RL19	6
2019004	RL19	8
2019005	RL19	10
2019006	RL19	12

### L INTERMEDIÁRIO (R21)



Código	Ref.	Ø
2L21001	RL21	4
2021002	R21	5
2L21003	RL21	6
2L21004	RL21	8
2021005	RL21	10
2021006	RL21	12

### Y ENTRADA ROSCA MACHO (RL23M)



Código	Ref.	Ø	Rosca
2L23401	RL23/M	4	M5
2L23402	RL23/M	4	1/8
2L23403	RL23/M	4	1/4
2L23406	RL23/M	6	1/8
2L23407	RL23/M	6	1/4
2L23409	RL23/M	8	1/8
2L23410	RL23/M	8	1/4
2L23412	RL23/M	8	3/8
2L23413	RL23/M	10	1/4
2L23415	RL23/M	10	3/8
2L23419	RL23/M	12	3/8
2L23420	RL23/M	12	1/2

### ANEL SIMPLES (R28)



Código	Ref.	Ø	Ø PARA:
2012102	R28	4	1/8
2012104	R28	5	1/8
2012106	R28	6	1/8
2012107	R28	6	1/4
2012108	R28	8	1/8
2012109	R28	8	1/4
2012110	R28	8	3/8
2012111	R28	10	1/4
2012112	R28	10	3/8
2012113	R28	12	1/4
2012114	R28	12	3/8
2012115	R28	12	1/2

Para hastes série D

### COTOVELO MACHO ANEL SIMPLES GIRATÓRIO (R20)



Código	Ref.	Ø	Rosca
2020001	RL20	4	M5
2020002	RL20	4	1/8
2020003	R20	5	M5
2020004	R20	5	1/8
2020016	RL20	6	M5
2020005	RL20	6	1/8
2020007	RL20	6	1/4
2020006	RL20	8	1/8
2020008	RL20	8	1/4
2020009	RL20	10	1/4
2L20017	RL20	10	3/8
2020010	RL20	12	1/4
2020011	RL20	12	3/8
2020012	RL20	12	1/2

### T INTERMEDIÁRIO (R22)



Código	Ref.	Ø
2L22001	RL22	4
2022002	R22	5
2L22003	RL22	6
2L22004	RL22	8
2022005	RL22	10
2022006	RL22	12

### Y ADAPTADOR (R24)



Código	Ref.	Ø1	Ø2 X 2
2024001	RL24	4	4
2024003	RL24	6	6
2L24004	RL24	8	8
2L24005	RL24	10	10
2L24006	RL24	12	12
2L24301	RL24	6	4
2L24303	RL24	8	6
2L24306	RL24	10	8
2L24309	RL24	12	10

### ANEL DUPLO (R29)



Código	Ref.	Ø	Ø PARA:
2013102	R29	4	1/8
2013104	R29	5	1/8
2013106	R29	6	1/8
2013107	R29	6	1/4
2013108	R29	8	1/8
2013109	R29	8	1/4
2013110	R29	8	3/8
2013111	R29	10	1/4
2013112	R29	10	3/8
2013113	R29	12	1/4
2013114	R29	12	3/8
2013115	R29	12	1/2

Para hastes série D

### T MACHO ANEL DUPLO GIRATÓRIO (R20A)



Código	Ref.	Ø	Rosca
2020A01	R20/A	4	M5
2020A02	R20/A	4	1/8
2020A03	R20/A	5	M5
2020A04	R20/A	5	1/8
2020A05	R20/A	6	1/8
2020A07	R20/A	6	1/4
2020A06	R20/A	8	1/8
2020A08	R20/A	8	1/4
2020A09	R20/A	10	1/4
2020A10	R20/A	12	1/4
2020A11	R20/A	12	3/8
2020A12	R20/A	12	1/2

### Y (R23)



Código	Ref.	Ø1	Ø2 X 2
2023001	RL23	4	4
2023002	R23	5	5
2023003	RL23	6	6
2023004	RL23	8	8
2L23005	RL23	10	10
2L23006	RL23	12	12
2L23301	RL23	6	4
2L23303	RL23	8	6
2L23306	RL23	10	8
2L23309	RL23	12	10

### Y LATERAL MACHO (RL25)



Código	Ref.	Ø	Rosca
2L25001	RL25	4	M5
2L25002	RL25	4	M7
2L25003	RL25	4	1/8
2L25004	RL25	6	1/8
2L25005	RL25	6	1/4
2L25008	RL25	8	1/4
2L25009	RL25	8	3/8

### L MACHO GIRATÓRIO (RL34)



Código	Ref.	Ø	Rosca
2L34001	RL34	4	M5
2L34020	RL34	4	M7
2L34002	RL34	4	1/8
2L34003	RL34	4	1/4
2L34006	RL34	6	M5
2L34021	RL34	6	M7
2L34007	RL34	6	1/8
2L34008	RL34	6	1/4
2L34009	RL34	8	1/8
2L34010	RL34	8	1/4
2L34011	RL34	8	3/8
2L34013	RL34	10	1/4
2L34014	RL34	10	3/8
2L34016	RL34	12	3/8
2L34017	RL34	12	1/2

**L FÊMEA GIRATÓRIO (RL34F)**


Código	Ref.	Ø	Rosca
2L34F01	RL34/F	4	M5
2L34F05	RL34/F	4	1/8
2L34F06	RL34/F	6	M5
2L34F07	RL34/F	6	1/8
2L34F08	RL34/F	6	1/4
2L34F09	RL34/F	8	1/8
2L34F10	RL34/F	8	1/4
2L34F13	RL34/F	10	1/4
2L34F14	RL34/F	10	3/8
2L34F16	RL34/F	12	3/8
2L34F17	RL34/F	12	1/2

**L MACHO PROLONGADO GIRATÓRIO (RL36)**


Código	Ref.	Ø	Rosca
2L36001	RL36	4	M5
2L36020	RL36	4	M7
2L36002	RL36	4	1/8
2L36006	RL36	6	M5
2L36021	RL36	6	M7
2L36007	RL36	6	1/8
2L36008	RL36	6	1/4
2L36009	RL36	8	1/8
2L36010	RL36	8	1/4
2L36012	RL36	10	1/4

**Y DUPLO ENTRADA ROSCA MACHO (RL43)**


Código	Ref.	Ø1	Rosca
2L43001	RL43	4	M5
2L43002	RL43	4	1/8
2L43003	RL43	4	1/4
2L43008	RL43	6	1/8
2L43009	RL43	6	1/4

**CURVA DE UNIÃO TIPO ENGATE (RL46)**


Código	Ref.	Ø
2L46001	RL46	4
2L46002	RL46	6
2L46003	RL46	8
2L46004	RL46	10

**T CENTRAL MACHO (RL35)**


Código	Ref.	Ø	Rosca
2L35001	RL35	4	M5
2L35020	RL35	4	M7
2L35002	RL35	4	1/8
2L35003	RL35	4	1/4
2L35006	RL35	6	M5
2L35007	RL35	6	1/8
2L35008	RL35	6	1/4
2L35009	RL35	8	1/8
2L35010	RL35	8	1/4
2L35011	RL35	8	3/8
2L35013	RL35	10	1/4
2L35014	RL35	10	3/8
2L35016	RL35	12	3/8
2L35017	RL35	12	1/2

**T MACHO PROLONGADO GIRATÓRIO (RL37)**


Código	Ref.	Ø	Rosca
2L37001	RL37	4	M5
2L37020	RL37	4	M7
2L37002	RL37	4	1/8
2L37006	RL37	6	M5
2L37007	RL37	6	1/8
2L37008	RL37	6	1/4
2L37009	RL37	8	1/8
2L37010	RL37	8	1/4
2L37012	RL37	10	1/4

**DISTRIBUIDOR MÚLTIPLO (RL44)**


Código	Ref.	Ø1 X 2	Ø2 X 3
2L44001	RL44	6	4
2L44003	RL44	8	6

**CURVA DE UNIÃO TIPO ENGATE COM PROLONGAMENTO (RL47)**


Código	Ref.	Ø
2L47001	RL47	4
2L47002	RL47	6
2L47003	RL47	8

**T CENTRAL FÊMEA GIRATÓRIO (RL35F)**


Código	Ref.	Ø	Rosca
2L35F01	RL35/F	4	M5
2L35F06	RL35/F	6	M5
2L35F07	RL35/F	6	1/8
2L35F08	RL35/F	6	1/4
2L35F09	RL35/F	8	1/8
2L35F10	RL35/F	8	1/4
2L35F13	RL35/F	10	1/4
2L35F14	RL35/F	10	3/8
2L35F16	RL35/F	12	3/8
2L35F17	RL35/F	12	1/2

**Y DUPLO (RL42)**


Código	Ref.	Ø1 X 4	Ø2
2L42001	RL42	4	4
2L42002	RL42	4	6
2L42004	RL42	6	6
2L42005	RL42	6	8

**DISTRIBUIDOR MÚLTIPLO ENTRADA ROSCA MACHO (RL45)**


Código	Ref.	Rosca	Ø1	Ø2 X 3
2L45001	RL45	1/8	6	4
2L45002	RL45	1/4	6	4
2L45007	RL45	1/8	8	6
2L45008	RL45	1/4	8	6
2L45009	RL45	3/8	8	6

**T CENTRAL TIGO ENGATE (RL48)**


Código	Ref.	Ø
2L48001	RL48	4
2L48002	RL48	6
2L48003	RL48	8
2L48004	RL48	10

**T LATERAL TIPO ENGATE (RL49)**


Código	Ref.	Ø
2L49001	RL49	4
2L49003	RL49	6
2L49004	RL49	8
2L49005	RL49	10
2L49006	RL49	12